

1 • Health and Safety Information

WARNING: PLEASE CAREFULLY READ THE SEPARATE HEALTH AND SAFETY PRECAUTIONS BOOKLET INCLUDED WITH THIS PRODUCT BEFORE USING YOUR NINTENDO® HARDWARE SYSTEM, GAMES, OR ACCESSORIES. THIS BOOKLET CONTAINS IMPORTANT HEALTH AND SAFETY INFORMATION.



WARNING - Injury Due to Pre-existing Conditions

Using the Pokéwalker accessory may require varying amounts of physical activity. Consult a doctor before using this product if:

- you are or may be pregnant,
- you have heart, respiratory, back, joint, or other orthopedic conditions,
- you have high blood pressure,
- you have difficulty with physical exercise, or
- you have been instructed to restrict physical activity.

While using this accessory, if you experience excessive fatigue, shortness of breath, chest tightness, dizziness, discomfort, or pain, STOP USE IMMEDIATELY and consult a doctor.

2 • Usage Guidelines

IMPORTANT: To avoid damage to the Pokéwalker accessory, do not place it in a location where excessive force could be applied, such as your back pants pocket. Sitting on it could result in injury to the user or damage to the accessory.

- Remove and dispose of the plastic tab in the battery compartment when you are ready to use the Pokéwalker for the first time.
- If you replace the battery or attach the clip connector, make sure that the water-resistant seal is correctly placed and the screw is securely tightened. This will help prevent any type of moisture from entering the battery compartment and damaging the accessory or battery. The Pokéwalker is moisture resistant but may be damaged if immersed in liquid.
- If the accessory gets dirty, clean it using a soft cloth slightly dampened with water only and a mild soap. Wipe dry with a soft cloth.

Be sure to remove the Pokéwalker accessory from clothing before washing.